

**CPYRGHT** 

## OPTICAL FLATS FOR TESTING MICROMETERS MODEL TIM



The Parallel-sided Optical Flats Model  $\Pi M$  provide a very convenient method of checking the flatness and parallelism of measuring faces on micrometers and other measuring apparatus.

The Optical Flats comprise plates of glass with both faces optically worked and polished to an extremely high degree of accuracy. The error in parallelism between the two working surfaces of the flat is within 0,5 microns, and the error in flatness is 0.1 micron.

When the flat face is placed in contact with a nominally flat lapped or polished surface, coloured interference bands can be seen. These are due to the interference of light between the optical flat and the test surface. The spacing of the bands forms the standard of measurement and successive bands represent differences of separation of the two surfaces of half a wavelength, i. e. almost exactly — 0.0003 mm.

By closing the micrometer measuring faces on the flat and manipulating so that one face shows no bands or only rings, the sum of the number of bands or rings on the two faces indicates the error in parallelism in units of 0.3 microns.

Lack of squareness of both faces to the axis of the micrometer screw will introduce variations in parallelism as the thimble is rotated. It is therefore, necessary to check with several flats of different thicknesses. The  $\Pi M$  set of micrometer flats comprises four flats, and their thicknesses are arranged to test at four 90° positions of rotation.

The  $\Pi M$  optical Flats are furnished in three nominal thicknesses designated as  $\Pi M$ -12,  $\Pi M$ -25,  $\Pi M$ -50 and in six sets.

The set of optical flats comes complete in a felt-lined case.



#### **TIM OPTICAL FLATS**

Flat thickness mm Set number		IIM	-12			IIM	1 - 25			ПМ	- 50	
1	12.00	12.12	12.25	12.37	25.00	25.12	25.25	25.37	50.00	50.12	50.25	50.37
11	12.12	12.25	12.37	12.50	25.12	25.25	25.37	<b>25.</b> 50	50.12	50.25	50.37	50.50
Ш	12.25	12.37	12.50	1 <b>2.</b> 62	25 <b>.25</b>	25.37	25.50	25.62	50.25	50.37	50.50	50.62
IV	12.37	12.50	12.62	12.75	25.37	25.50	25.62	25.75	50.37	50.50	50.62	50.75
٧	12.50	12.62	12.75	12.87	25.50	25.62	25.75	25.87	50.50	50.62	50.75	50.87
VI	12.62	12.75	12.87	13.00	25.62	25.75	25.87	26.00	50.62	50.75	50.87	51.00
	ı	1	1	l	1	I		1	ŀ			i

### THE ALL-UNION CORPORATION

### "STANKOIMPORT"

EXPORTS AND IMPORTS:


Machine Tools • Metal-Working Machinery • Wood-Working Machinery • Measuring Instruments and Apparatus • Metal and Wood-Cutting Tools • Portable Electric and Pneumatic Tools • Carbide Tips and Special Carbide Products • Grinding Wheels • Ball and Roller Bearings • Metallurgical, Biological and Medical Microscopes • Movie Equipment and Accessories • Geodetic Apparatus and Instruments • Photocameras, Binoculars, Magnifiers, Lenses etc.

Detailed catalogues and pamphlets sent on request. All inquiries and correspondence to be forwarded to

VIO "STANKOIMPORT"

ul. Kuibysheva, 21, Moscow, USSR. For cables: Stankoimport, Moscow.

## MICROSCOPE FOR MEASURING SPECTOGRAMS MODEL MUP-12



The model MUP-12 microscope is an instrument especially adapted to the measurement of spectrograms.

It may also be used for many other measuring purposes.

Accuracy of measurement, mm		10.0
Range of measurements, in longitudinal direction or y, mm	 	from 0 to 50
Magnification of microscope		
Field of view, mm		
Magnification of objective		3×
Numerical Aperture of objective		0.1
Resolving power of objective, mm		0.003

### ACCESSORIES

Object glass plate Set of accessories



### "STANKOIMPORT" EXPORTS AND IMPORTS:

Machine Tools • Metal-Working Machinery • Wood-Working Machinery • Measuring Instruments and Apparatus • Metal and Wood-Cutting Tools • Portable Electric and Pneumatic Tools • Carbide Tips and Special Carbide Products • Grinding Wheels • Ball and Roller Bearings • Metallurgical, Biological and Medical Microscopes • Movie Equipment and Accessories • Geodetic Apparatus and Instruments • Photocameras, Binoculars, Magnifiers, Lenses etc.


Detailed catalogues and pamphlets sent on request. All inquiries and correspondence to be forwarded to

VIO "STANKOIMPORT"

ul. Kuibysheva, 21, Moscow, USSR. For cables: Stankoimport, Moscow.

### TOOLMAKERS MICROSCOPE MODEL MI

25X1A



The MT Toolmakers' Microscope is an accurate universal and rugged instrument designed for optical measuring and inspecting various angles or thread forms, tools, jigs, dies, templets and many other objects.

The Microscope is widely used by the machinist and toolmaker. Without sacrificing anything in accuracy it is adapted to the needs of the workshop as well as the mechanical laboratory.

The Microscope unit is focused by rack and pinion after rough adjustment on the ways of the support column. This column can be tilted through 12° each side of vertical by two screws. The Microscope eyepiece has a magnification of 9.1 x. In the reticle of the eyepiece are two crosslines, the angle between which may be varied. The reticle and the protractor circle are rotated simultaneously. By setting one of the crosshairs successively on the two sides of any angle and taking the difference of the two readings of the protractor circle the angle is accurately measured. The protractor circle scale is graduated to one degree and is observed through a separate microscope, which contains a reticle having 60 lines to embrace 1° on the scale, thus the protractor scale is 1 division = 1 minute.

The cross slide stage of the Toolmakers' Microscope has a range of 25 mm in either direction in the horizontal plane. The insertion of gauge blocks increases the longitudinal range to 75 mm. The stage rests on ball bearings, which assure a straight and almost frictionless motion controlled by two micrometer screws.



### Approved For Release 2002/01/04 : CIA-RDP83-00415R011900050001-3

### SPECIFICATIONS

Total magnification	27.3x
Magnification of objective	3x
Magnification of eyepiece	9.1x
Field of view, mm	6
Source of illumination	bulb, 25—40 w, 120—220 v.
Illumination control	by iris diaphragm
Protractor microscope	42x
Reading accuracy of protractor circle to, minutes	1
Range of microscope column tilt Assaulting Co	±12°
Stage travel in longitudinal and cross directions by micrometer screws, mm	25
Increased travel of stage in longitudinal direction by means of gauge blocks, mm	75
Accuracy of measurement of thread diameters, mm.	0.005
Accuracy of angular measurements, minutes	2
Overall dimensions, mm	450×475×340

### ACCESSORIES

Protractor unit

Clamp for small diameter objects
Centers and centers' support

V-block for holding centreless parts

Stage arbor

Clamp for small diameter objects
Object clamp and supports
Block gauges, 25 mm and 50 mm

Carrying case.

## THE ALL-UNION CORPORATION ,,STANKOIMPORT" EXPORTS AND IMPORTS:

Machine Tools • Metal-Working Machinery • Wood-Working Machinery • Measuring Instruments and Apparatus • Metal and Wood-Cutting Tools • Portable Electric and Pneumatic Tools • Carbide Tips and Special Carbide Products • Grinding Wheels • Ball and Roller Bearings • Metallurgical, Biological and Medical Microscopes • Movie Equipment and Accessories • Geodetic Apparatus and Instruments • Photocameras, Binoculars, Magnifiers, Lenses etc.

Detailed catalogues and pamphlets sent on request.

All inquiries and correspondence to be forwarded to

VIO "STANKOIMPORT"

ul. Kuibysheva, 21, Moscow, USSR. For cables: Stankoimport, Moscow.

Mežhdunarodnava Kniga

Approved For Release 2002/01/04 : CIA-RDP83-004 THIS IS AN ENGLOSURE TO


DO NOT DETACH

LARGE

TOOLMAKERS'

MICROSCOPE

MODEL **БМИ** 



The BMM Large Toolmakers' Microscope is an accurate, universal and rugged instrument designed for optical measuring and inspecting various angles or thread forms, tools, milling cutters, cams, templets and many other objects. It is intended to serve as a comprehensive measuring apparatus in the factory and laboratory.

The instrument consists essentially of a massive stand carrying a circular worktable with movements in two directions at right angles and controlled by micrometer screws. The table also has a circular motion. The microscope unit is mounted on a support column inclinable about a horizontal axis in order that the screw thread, when under observation, may be viewed from a normal to the helix angle. The protractor and thread forms are drawn on glass plates situated at the focal plane of the microscope eyepiece. To the upper end of the microscope are attached units containing a protractor or screw thread forms, which are visible in the field of view and are superimposed over the image of the object under test. Four objectives are available, which give initial magnifications of IX,  $1.5 \times .3 \times$ and 5 imes. The table slides are mounted on ball bearings which assure a straight and almost frictionless motion. The linear movements of the table controlled by the micrometer screws have a range of 25 mm in either direction in the horiziontal plane. The insertion of gauge blocks increases the longitudinal range to 150 mm and the cross range to 50 mm.



### Approved For Release 2002/01/04: CIA-RDP83-00415R011900050001-3

### **SPECIFICATIONS**

Range of total magnification	9	1 x to 45.5 x
Objectives	1	x-1.5x: 3x and 5x
Eyepiece	9	1x
Field of view, mm		
Reading accuracy of linear measurements, mm	. 0	005
Reading accuracy of angular measurements, minutes	. 1	
Table travel in longitudinal and transverse directions		
by micrometer screws, mm	. 2	5
Maximum table travel using gau <b>ge blocks, mm</b> :		
longitudinal	1.	50
transverse		37 4
Reading of table micrometer screws, mm		005 & & & & & & & & & & & & & & & & & &
Circular table graduated to 1°, reading to, minutes		305
	ა	25 2 3 3 5 5 5 5 5 5 5 5 5 5 5 5 5 5 5 5
Maximum distance between centers, mm:		
with work under 39 mm diameter達法		25 🦾 🔊
with work between 39 mm and 85 mm diam	31	5 🔊 🏂
Maximum diameter of centred work, mm	85	
Maximum diameter of work held in V-blocks, mm	13	0
Greatest distance between table and objective, mm	20	0
Depth of throat, mm	16	7
Range of microscope column inclination	±1	12° 30′
Source of microscope illumination ACALAGE COMMISSION AND ACACAGE COM	bu	0220 v
Protractor unit illumination	bu	b. 6 v. 0.35 amp.
Transformer for reducing A. C. mains (120-220 v.) down to		
Overall dimensions, mm		
Weight of instrument, kg	81	\$a

### STANDARD EQUIPMENT

Objectives 1x; 1.5x; 3x and 5x Protractor unit Transmitted light illuminator Thread template unit Centers' support V-guide V-block for holding centerless parts.

Object a ma-Set of grage blocks Illuminate for protractor unit Transformer Focusing attachment Carrying ase


### EQUIPMENT SUPPLIED AT EXTRA COST

Radius template unit Hole center distance measuring unit 30°, 40° 55° and 60° angle measuring enit Projection attachment with illuminator Camera attachment

Order No. 862

Mezhdunarodnaya Kniga

## UNIVERSAL MEASURING MICROSCOPE MODEL YMM-21



The YMM-21 Universal Measuring Microscope is a high precision, rugged instrument designed for optical measuring and inspecting lengths, angles and various forms of thread gauges, taps, chasers, hobs, form tools, templets, tapers, cams etc.

The instrument consists essentially of a massive stand carrying longitudinal slides on which the object under measurement is placed and transverse slides with main microscope unit and illuminator. Both longitudinal and transverse slides are mounted on ball bearings which assure a straight and almost frictionless motion. Two reading microscope units are fixed on the stand providing accurate readings in the longitudinal and transverse directions.

The main microscope unit is mounted on an inclinable support column in order that the screw thread, when under observation, may be viewed from a normal to the helix angle. The microscope has a vertical movement on the support column. Both rough and fine focusing are provided.

For angular measurements a protractor unit is supplied connecting with the body tube of the main microscope. The protractor unit scale is graduated and figured to one degree. The scale is observed through a separate microscope, which also contains a fixed reticule having 60 lines to embrace  $1^{\circ}$  on the scale, thus the protractor scale is 1 division = 1 minute.

The instrument should be housed in a dry room, installed on a solid foundation or on a support table and work at  $20^{\circ}$  C.



### Approved For Release 2002/01/04: CIA-RDP83-00415R011900050001-3

### SPECIFICATIONS

Maximum measuring range:    longitudinal, mm	Numerical apertule
Scale reading:  linear measurements, mm	LONGITUDINAL TRAVEL READING MICROSCOPS  Total magnification 60x  Field of view, m 2.3  Eyepiece movement per I diopter, mm 0.4  Numerical apertue 0.12  Objective magnification 5x  Recolving power of objective, mm 0.0025
Total magnification 30x field of view, mm 5.4 Numerical aperture 0.1 Objective magnification 3x Resolving power of objective, mm 0.003	TRANSVERSE TRAVEL READING MICROSCOPE  Foral magnifica on
PROTRACTOR UNIT MICROSCOPE  Fotal magnification	Overall dimensions of instrument, mm 1130x1030x800 Weight of instrument, kg

### **ACCESSORIES**


Protractor unit
Objective 3x
Measuring table with bar and two clamps
Testing gauge
Collimator
Reflector

Two measuring blade clamps
Three plates with clamping bolts
Two large internal work centers
Small internal work centers
Humination attachment
Sut of measuring blades (16 pieces)

Mezhdunarodnaya Kniga

25X1A

# SIMPLIFIED POLARIZING MICROSCOPE MODEL MVH-2



The Model MUH-2 Microscope is a simplified construction of the Polarizing Microscope MUH-1. It has been designed for mineralogical, petrological and crystallographic investigations as well as for medical and biological research work.



### Approved For Release 2002/01/04: CIA-RDP83-00415R011900050001-3

### **SPECIFICATIONS**

Range of total magnification
Achromatic objectives
Fyepreces
Objective changing device triple revolution nosepiece
Focusing adjustments:
coarse
fine
$tiliuminating \ system \ \dots \ nlame \ and \ concave \ mirrors, \ condenser \ with iris \ diaphragm$
Seaurce of illumination
Weight of microscope, kg
Weight of microscope with case, kg.,8.3

### **ACCESSORIES**

Set of two eyepiaces
Portable case

Lis trait List Que retr . Sec. 114

### ",STANKOIMPORT" EXPORTS AND IMPORTS:

Machine Tools • Metal-Working Machinery • Wood-Working Machinery • Measuring Instruments and Apparatus • Metal and Wood-Cutting Tools • Portable Electric and Pneumatic Tools • Carbide Tips and Special Carbide Products • Grinding Wheels • Ball and Roller Bearings • Metallurgical, Biological and Medical Microscopes • Movie Equipment and Accessories • Geodetic Apparatus and Instruments • Photocameras, Binoculars, Magnifiers, Lenses etc.

Detailed catalogues and pamphlets sent on request. All inquiries and correspondence to be forwarded to

VIO "STANKOIMPORT"

છો. Kuibysheva, 21, Moscow, USSR. For cables: Stankoimport, Moscow.


## BIOLOGICAL MICROSCOPE M-9

# RESTRICTED

The Model M-9 Microscope is a medium type biological microscope designed for the examination of transparent objects in transmitted light. Besides, opaque specimens too may be examined, in reflected light in low-power work.

The Model M-9 Microscope is the most universal and popular type of the biological microscopes and is widely employed in biological, medical, agricultural and various industrial laboratories, in universities and clinics.

The construction of the microscope, its fine optics, wide variety of accessories, positive and convenient operation, insure precision and excellent results in research work.





<u>V/o Stankoimport</u>
Moscow-ussr

### Approved For Release 2002/01/04: CIA-RDP83-00415R011900050001-3

### **SPECIFICATIONS**

Range of total magnification		1.250×
Achromatic objectives		
	and	'x all immersion 1.25 NA
Eyeuleces	/x. l	1 - ar 115x
wo lens condenser 1.20 N.A. with itis diaphragm		
Mirr arconcave on one side and plane on the other		
Ådjustable draw tube, extensible between, mm $\dots$		150 - 200
Draw tube araduated in millimeters with a special m	nark indicatio	n tube length of 160 mm
Course and fine focusing adjustments. The fine adjustme	ent drum is gr	tunted in 2-micron intervols
Stage	circ	If the volving and centers if
Weight of microscope with accessories in case, kg		9.5
Size of wood case, mm		290 × 200 × 1.32

#### ACCESSORIES

Set of three objectives Set of three eyepieces Partable case

### THE ALL-UNION CORPORATION

### "STANKOIMPORT"

EXPORTS AND IMPORTS:

Machine Tools • Metal-Working Machinery • Wood-Working Machinery • Measuring Instruments and Apparatus • Metal and Wood-Cutting Tools • Portable Electric and Pneumatic Tools • Carbide Tips and Special Carbide Products • Grinding Wheels • Ball and Roller Bearings • Metallurgical, Biological and Medical Microscopes • Movie Equipment and Accessories • Geodetic Apparatus and Instruments • Photocameras, Binoculars, Magnifiers, Lenses etc.


Detailed catalogues and pamphlets sent on request. All inquiries and correspondence to be forwarded to

VIO "STANKOIMPORT"

vl. Kuibysheva, 21, Moscow, USSR. For cables: Stankoimport, Moscow.

25X1A

## NON-RECORDING PHOTOELECTRIC MICROPHOTOMETER MODEL МФ-2



The NON-RECORDING PHOTOELECTRIC MICROPHOTOMETER **MФ-2** is designed for rapid and precise measurement of the density of lines in spectrograms on the photographic plates.

For routine methods of quantitative spectrum analysis the microphotometer is found to give the most rapid consistent results.

### **SPECIFICATIONS**

Range of magnification 21 x to 30 x	Heigth of microphotometer, mm 550
Range of magnification 21x 10 30x	Weight of misraphotometer kg 48
Objective	Weight of microphotometer, kg
Lamp of optical system 12 v., 30 w.	Weight, complete with all accessories, kg 186

### **ACCESSORIES**

Accumulator battery Rectifier D. C. Voltmeter Rheostat Spare parts



### THE ALL-UNION CORPORATION.

### "STANKOIMPORT"

EXPORTS AND IMPORTS

Machine Tools • Metal-Working Machinery • Wood-Working Machinery • Measuring Instruments and Apparatus • Metal and Wood Cutting Tools • Portable Electric and Pneumatic Tools • Carbide Tips and Special Carbide Products • Grinding Wheels • Ball and Roller Bearings • Metalurgical, Biological and Medical Microscopes • Movie Equipment and Accessories • Geodetic Apparatus and Instruments • Photocameras, Binoculars, Magnifiers, Lenses etc.

Detailed catalogues and pamphlets sent on request All inquiries and correspondence to be forwarded to

VIO "STANKOIMPORT"

ਯ. Kuibysheva, 21, Moscow, USSR. For cables: Stankoimport, Moscow.


Orler Nr 741

THIS IS AN ENCLOSURE TO DO NOT DÉTACH



25X1A

## ALIDADE WITH PLANE TABLE MODEL KB



The ALIDADE WITH PLANE TABLE **HB** has been designed for laying out angles, plotting contour lines and making maps directly from the measurements made in the field.

The Alidade is characterized by fine optics, durability and ease of adjustment.

The construction of the Plane Table drawing board prevents warping.



### Approved For Release 2002/01/04: CIA-RDP83-00415R011900050001-3

### **SPECIFICATIONS**

Magnification of talescope	. 25 x
hald of view	
Magnification of magnifier	
Resolving power of telescope	
Escal longth of objective, mm.	480
focal length of eyepieco are a consequence.	 . 15
Aperture of objective, mm.	34
Vertical circle divided to	 .301
Circle reading by vernier to	 . I'
Sensitivity of blade level	
Substitivity of atidade level	 . 301.50"
Compass scale divided to	 . 30
cough of blade, man,	. 530
"Fight of optical axis above the occasi, min.	 . 205
Lingth of tripod, mm	
Size o liptane table drawing board, mm.	
Weight of aildade, kg	
Weight of pame table, kg	. 5.5
Weight of drawing board, kg	4.5
Weight of irrood, kg	
Weigh of addude in case with compass, kg.	[4]
Weight of pluse table in case, keepers	13.3
Weight of drawing board to position as a ko-	6.5

### **ACCESSORIES**

Figod Deciving board Compati Comp

## ",STANKOIMPORT" EXPORTS AND IMPORTS:

Machine Tools • Metal-Working Machinery • Wood-Working Machinery • Measuring Instruments and Apparatus • Metal and Wood-Cutting Tools • Portable Electric and Pneumatic Tools • Carbide Tips and Special Carbide Products • Grinding Wheels • Ball and Roller Bearings • Metallurgical, Biological and Medical Microscopes • Movie Equipment and Accessories • Geodetic Apparatus and Instruments • Photocameras, Binoculars, Magnifiers, Lenses etc.

Detailed catalogues and pamphlets sent on request.

All inquiries and correspondence to be forwarded to

VIO "STANKOIMPORT"

ul. Kuibysheva, 21, Moscow, USSR. For cables: Stankoimport, Moscow.


h r No. /41

THIS IS AN ENCLOSURE TO

DO NOT DETACH

25X1A

## OPTICAL THEODOLITE MODEL **OT-10**



The OPTICAL-THEODOLITE **OT-10** is a geodetic instrument designed for measuring horizontal and vertical angles.

It is exceptionally neat and compact in design and reads directly to 20 seconds with precision and combines accuracy of reading with simplicity of operation.



### Approved For Release 2002/01/04: CIA-RDP83-00415R011900050001-3

#### SPECIFICATIONS

Magnification of telescope	25.3 x
Field of view	1" 10"
Aparture of objective, mm	40
rocal length of objective, mm	250
Shortest focusing distance of telescope, m	1.5
Optical micrometer for reading the horizontal and vertical circle, direct to	20″
Scales of horizontal and vertical circles graduateri to	201
Sensitivity of plate level per 2 mm. run	40"-60″
Sensitivity of altitude level per 2 mm. rur	15″-20 <b>″</b>
Weight of instrument, kg.	6.3
Weight of instrument in case with accessories, k	17
Weight of tripod, kg.	5.8
Weight of box for transporting the instrument, kç	13
Total weight, kg	35.8

### **ACCESSORIES**

Eyepiece prism Sliding leg tripod Portable case Transporting box Tribulation of the state of the

### ",STANKOIMPORT" EXPORTS AND IMPORTS:

Machine Tools • Metal-Working Machinery • Wood-Working Machinery • Measuring Instruments and Apparatus • Metal and Wood-Cutting Tools • Portable Electric and Pneumatic Tools • Carbide Tips and Special Carbide Products • Grinding Wheels • Ball and Roller Bearings • Metallurgical, Biological and Medical Microscopes • Movie Equipment and Accessories • Geodetic Apparatus Apparatus • Metallurgical Products • Movie Equipment and Accessories • Geodetic Apparatus • Metallurgical Products • Metallurg

Detailed catalogues and pamphlets sent on request. All inquiries and correspondence to be forwarded to

ratus and Instruments • Photocameras, Binoculars, Magnifiers, Lenses etc.

VIO "STANKOIMPORT"

ul. Kuibysheva, 21, Moscow, USSR. For cables: Stankoimport, Moscow.


## TRIANGULATION THEODOLITE MODEL TT2/6

The TT 2/6 Triangulation Theodolite is designed for measuring horizontal angles and zenith distances with the degree of accuracy necessary in first order work.

It is an extremely accurate and reliable instrument having a horizontal graduated circle and a vertical arc.

Separate optical systems for reading the horizontal circle and the vertical arc are provided, the method of reading being simple and direct.

The horizontal circle is read by two optical micrometers to an accuracy of 2".



The vertical arc reading is by two microscopes to an accuracy of  $6^{\prime\prime}$ .

The telescope permits measurement of angles between points situated at a distance of up to 60 km from the instrument.

For night work the instrument is supplied with an electric illumination.

#### TELESCOPE HORIZONTAL CIRCLE READING Total regnification ..... 52 x and 65 x MICROSCOPES Field of vinw ...... - 0°43 an ±0°371 Augnification Resolving power of objective . . . . . 2151 Micrometer en las de diam reading. Focal length of objective, mm. . . . 520 VERTICAL ARC READING Micrometer eyepiece drum reading MICROSCOPES Overall length of telescope, mm ... 623 Acgnication 48 × country of kinds (1) AUXILIARY TELESCOPE Aperture of objective, mm. ... Focal ength of objective, mm . 36) DIME STONS AND WEIGHT Focal length of eyepi-ces, mm . . . . . 12 -ghtofirstr -- mm . . . vereildamen - occuryang cases, tim . 420 × 424 x 400 Micro notes eyopiece drum reading 207 €300 x 600

toght of the control corrying.

45 %

rses, kg .

### VSESOJUZNOE EXPORTNO-IMPORTNOJE OBJEDINENIJE

Overa Hength of telescope, mm... 380

### "STANKOIMPORT"

EXPORTS AND IMPORTS

Machine Tools • Metal-Working Machinery • Wood-Working Machinery • Measuring Instruments and Apparatus • Metal and Wood-Cutting Tools • Portable Electric and Pneumatic Tools • Carbide Tios and Special Carbide Products • Grinding Wheels • Ball and Roller Bearings • Metallurgical, Biological and Medical Microscopes • Movie Equipment and Accessories • Geodetic Apparatus and Instruments • Photocameras, Binoculars, Magnifiers, Lenses, etc.

Detailed catalogues and pamphlets sent on request. All inquiries and correspondence to be forwarded to

V/O "STANKOIMPORT"

ul. Kuibysheva, 21, Moscow, USSR. For cables: Stankoimport Moscow.

25X1A

## THEODOLITE TACHEOMETER MODEL TT-2



The THEODOLITE TACHEOMETER **TT-2** is a geodetic instrument designed for measuring horizontal and vertical angles, as well as for determining distances with a stadia and a geodetic rod graduated in centimeters. It is a high-grade instrument, compact in design, simple and efficient in use. It reads directly to 30 seconds with precision.



Magnification of telescope	-	7×
field of view		3:10:
Resolving power of objective		551
Focal length of objective, mm		i 80
Stadia lines		1:100
Sensitivity of horizontal circle level		401-30"
Reading of horizontal and vertical circles		30"
Shortest focusing distance of telescope, m		20
Weight of instrument, kg		5.4
Weight of instrument in case with accessories, ka		118
Weight of tripod, kg.		58
Total weight, kg		176

### ACCESSORIES

Compass

Tripod

Portable case

### THE ALL-UNION CORPORATION ,,,STANKOIMPORT"

**EXPORTS AND IMPORTS:** 

Machine Tools • Metal-Working Machinery • Wood-Working Machinery • Measuring Instruments and Apparatus • Metal and Wood-Cutting Tools • Portable Electric and Pneumatic Tools • Carbide Tips and Special Carbide Products • Grinding Wheels • Ball and Roller Bearings • Metallurgical, Biological and Medical Microscopes • Movie Equipment and Accessories • Geodetic Apparatus and Instruments • Photocameras, Binoculars, Magnifiers, Lenses etc.

Detailed catalogues and pamphlets sent on request. All inquiries and correspondence to be forwarded to

VIO "STANKOIMPORT"


ul. Kuibysheva, 21, Moscow, USSR. For cables: Stankoimport, Moscow.

Corp. No. 741 Printed in the USSK

25X1A

DO NOT DETACH

## PILOT BALLOON THEODOLITE MODEL **ШT**



The PILOT BALLOON THEODOLITE LLT is an instrument the construction of which allows to determine the azimuth and elevation position of pilot balloons. The horizontal and vertical angles are read on two circles to an accuracy of 0.1°.



Magnification of telescope	 12 ←
hield of view of telescope	 30 45*
Horizontal and vortical circles graduated to	13
Reading of circles to an accuracy or	0.15
Sensitivity of level per 0.6 mm	 6'
Weight of instrument, kg	 4.9
Weight of tripod, kg	 6.1
Weight of instrument, complete set, kg	17.5
Overall size of instrument case, mm	200° x 25°) x <b>34</b> ()
Overall size of battery box, mm	125 x 11.) < 160
Overall size of tee case, mm	 120 x 130 x 110
Longth of tripod, mm,	9.51

### ACCESSORIES

Cripod

Box with batteries

Tee for illumination

Cases

## ",STANKOIMPORT" EXPORTS AND IMPORTS:

Machine Tools • Metal-Working Machinery • Wood-Working Machinery • Measuring Instruments and Apparatus • Metal and Wood-Cutting Tools • Portable Electric and Pneumatic Tools • Carbide Tips and Special Carbide Products • Grinding Wheels • Ball and Roller Bearings • Metallurgical, Biological and Medical Microscopes • Movie Equipment and Accessories • Geodetic Apparatus and Instruments • Photocameras, Binoculars, Magnifiers, Lenses etc.

Detailed catalogues and pamphlets sent on request. All inquiries and correspondence to be forwarded to

V/O "STANKOIMPORT"

ul. Kuibysheva, 21, Moscow, USSR. For cables: Stankoimport, Moscow.

DO NOT BETACH

### CAPILLAROSCOPE MODEL M 70A


The Model M 70 A Capillaroscope is a microscope with an illuminator which permits visual examination of objects in reflected light.

This instrument may be used as a vertical microscope for the examination of capillaries in the finger-nail limb; as a horizontal microscope for the examination of capillaries in the lip and tongue mucous membrane, or as a portable microscope for the examination of capillaries in the outward tissues of the body.

Two interchangeable eyepieces give a total magnification of 28x and 70x, and a ruled micrometer disc placed in one of the microscope eyepieces (4x) permits to make accurate measurements to 0.05 mm.

The micrometer disc scale (1 mm. long) has 20 divisions with every fourth division indicated by a numbered line. Each interval in the scale between two lines of double length is equivalent to 0.1 mm. on the object.

The eye lens is adjustable for focusing on the scale, the range of adjustment being  $\pm$  4 diopters. The objective is corrected ( $^{2}/_{3}$  of field) for spherical and chromatic aberration and curvature of field.



The Capillarroscope M70A may be used successfully both for medical and other purposes requiring examination of objects in reflected light (textile, paper, printing and publishing industries, laboratories, etc.).



Total magnification	28 x and 70 x
Objective	7x, 0.18 N.A.
Eyepieces	$4 < \text{and} 10 \times$
Field of view:	
with eyeprece 10x, mm.	2.2
with eyepiece 4x, mm	3 4
Scale reading of micrometer disc, mm	0.05
fotal adjustment of sliding tube, mm	50
Range of eye lens adjustment, diopters	± 4
Bulb in centring housing	13.5 v, 0.18 amp

#### **ACCESSORIES**

Stone

Cleaning flannel cloth

Fixture for the examination of Figer-nail cap and fixture for the examination of mixous membine capitlaries fixture for the examination of a tward tissue capitlaries. Findle Additional disc for placing the object. Bailbut contains nousing — 5 pieces. Fransformer FP-MI. Carrying case.

The toric the late of the late

THE ALL-UNION CORPORATION

### "STANKOIMPORT"

EXPORTS AND IMPORTS:

Machine Tools • Metal-Working Machinery • Wood-Working Machinery • Measuring Instruments and Apparatus • Metal and Wood-Cutting Tools • Portable Electric and Pneumatic Tools • Carbide Tips and Special Carbide Products • Grinding Wheels • Ball and Roller Bearings • Metallurgical, Biological and Medical Microscopes • Movie Equipment and Accessories • Geodetic Apparatus and Instruments • Photocameras, Binoculars, Magnifiers, Lenses etc.

Detailed catalogues and pamphlets sent on request. All inquiries and correspondence to be forwarded to

Y/O "STANKOIMPORT"


el. Kuibysheva, 21, Moscow, USSR. For cables: Stankoimport, Moscow.

Order No. 741 Printed in the USSR

THIS IS AN ENCLOSURE TO DO NOT DETACH

25X1A

## THREE-PRISM GLASS SPECTROGRAPH MODEL **ИСП-51**



The UCП-51 Three-Prism Glass Spectrograph has been designed for emission and absorption analyses, investigation and photographing of spectra.

It has principally been employed for many purposes where high dispersion is required over the visible region of the spectrum, particularly for the study of complex spectra, flame spectra and for investigating the spectra of feeble sources of light such as fluorescence etc.

The base of the spectrograph is constructed to take a bar on which a number of accessories can be mounted in correct alignment in front of the slit. The length of the bar is 1500 mm. The slit is of the symmetrical type operated by a drum graduated to indicate slit widths. The divisions are well separated permitting estimation of slit widths to a single micron. The dispersing system consists of three prisms: two of the equiangular design and one of the Abbe type.

The instrument has two interchangeable cameras: one with 120 mm. objective focal length — for spectra of feeble sources of light and the other — 270 mm. objective focal length — for work requiring higher spectrum dispersion.

Collimator objective:	
focal length, mm	3 14 /
hull aperture	
diameter, mm	6)
Width of collimator slit, mm	adjustable from 0 tr 03
E-sms:	
refracting angle	· 3
buse, mm	
Storchangeable cameras	
Lieut comera:	
objective local length, mm	2/0
full aperture	
Second camera:	
objective focal length, mm	120
full aporture	{
5 ze of plate, cm	65x+
Overall dimensions of instrument (length x width x height	n, min
leight of optical axis above table surface. mm	5 <b>0</b>
Weight of instrument (with bar), kg	
Weight of instrument in carrying case *q	1 1/1

### **ACCESSORIES**

But
Two interchangeable can eras
Strinsen with compared orise
Disphraym
Studier
Self of source parts and incode 100 s
Clarying case

### VSESOJUZNOE EXPORTNO-IMPORTNOJE OBJEDINENIJE

### "STANKOIMPORT"

EXPORTS AND IMPORTS:

Machine Tools • Metal-Working Machinery • Wood-Working Machinery • Measuring Instruments and Apparatus • Metal and Wood-Cutting Tools • Portable Electric and Pneumatic Tools • Carbide Tips and Special Carbide Products • Grinding Wheels • Ball and Roller Bearings • Metallurgical, Biological and Medical Microscopes • Movie Equipment and Accessories • Geodetic Apparatus and Instruments • Photocameras, Binoculars, Magnifiers, Lenses, etc.

Detailed catalogues and pamphlets sent on request. All inquiries and correspondence to be forwarded to


V/O "STANKOIMPORT"

ul. Kuibysheva, 21, Moscow, USSR. For cables: Stankpimport Moscow.

DO NOT DETACH



### PORTABLE STEELOSCOPE MODEL CIT-1



The CAII-1 Portable Steeloscope is a specialised spectroscope designed for the rapid qualitative and approximate quantitative analysis of metallic elements in steels. The instrument enables the presence of the metals Chromium, Nickel, Tungsten, Vanadium, Cobalt, Molybdenum and Manganese to be detected at once in steel bars, steel scrap or steel work-pieces even by an unskilled observer.

Specimens of the alloy under examination are used as the poles of an electric arc, and the light from this is spread out by the steeloscope into a series of lines whose positions are distinctive of the metals present in the specimens.

The Portable Steeloscope finds wide application in metallurgical works, rolling mills and metal working industries for the rapid control of steels, where it is inconvenient or difficult to take the specimen to a stationary type steeloscope.

### SPECIFICATIONS

Spectrum range 3890 Å7080Å	Focal length of condenser, mm 58.3
Angle of beam incident on prism 610	Focal length of objective, mm 322.2
Magnification of instrument II.IX	Focal length of eyepiece, mm 28.8
Field of view	Current required

### VSESOJUZNOE EXPORTNO-IMPORTNOJE CBJEDINENIJE

### "STANKOIMPORT"

EXPORTS AND IMPORTS:

Machine Tools • Metal-Working Machinery • Wood-Working Machinery • Measuring Instruments and Apparatus • Metal and Wood-Cutting Tools • Portable Electric and Pneumatic Tools • Carbide Tips and Special Carbide Products • Grinding Wheels • Ball and Roller Bearings • Metallargical, Biological and Medical Microscopes • Movie Equipment and Accessories • Geodetic Apparatus and Instruments • Photocameras, Binoculars, Magnifiers, Lenses, etc.


Detailed catalogues and pamphlets sent or request.

All inquiries and correspondence to be forwarded to

V/O "STANKOIMPORT"

ul. Kuibysheva, 21, Moscow, USSR. For cables: Stankoimport Moscow.

### UNIVERSAL MONOCHROMATOR MODEL **YM-1**



The yM-1 Universal Monochromator is an instrument of the constant deviation type with wave-length scale. It can effectively be used as a monochromator or as a spectroscope.

The prism system consists of two rotating prisms so arranged as to reduce doubling of images to the minimum and to prevent reflections.

The telescope and collimator are both rigidly fixed, since to pass through the spectrum it is only necessary to rotate the prisms; and as a result a construction is arrived at which is at once extremely convenient and mechanically sound.

The prisms are rotated by means of a micrometer screw to which is fixed a drum on which the wave length of the line under observation is read by the observer without quitting the eyepiece.

The collimator slit is of the symmetrically moving type, of efficient design and is completely enclosed. The micrometer screw has an adjustable drum graduated to read to 0.01 mm slit width.

The instrument is widely used in research and workshop laboratories.

Spectrum range		3	300A to 10000A"	
Dispersing system		ant deviation type		
Refracting angle of prisms			60"	
Angle of rotation of prisms within spectrum working range	:			
prism I			4146-21"	
prism II				
Collinator objective:				
focal length, mm			280	
aperture ratio				
Athromatic condenser:				
focal length, mm			37.	
lens diameter, mm				
Colimator slit:				
height, mm			15	
adjustable width, mm			from 3 to 1.5	
Magnification of eyepieces				
Imear magnification of spectroscope				•
Overall aimensions of instrument, mm			520 x 490 x 360	
Oye all dimensions of instrument on bars are				

#### ACCESSORIES

Support with acricumum, condensed Lwo Forcers with larger Lwo Forcers and LV cottony Set of source parts Contrying caso.

### VSESOJUZNOE EXPORTNO-IMPORTNOJE CBJEDINENIJE

### "STANKOIMPORT"

EXPORTS AND IMPORTS:

Machine Tools • Metal-Working Machinery • Wood-Working Machinery • Measuring Instruments and Apparatus • Metal and Wood-Cutting Tools • Portable Electric and Pneumatic Tools • Carbide Tips and Special Carbide Products • Grinding Wheels • Ball and Roller Bearings • Metaliurgical, Biological and Medical Microscopes • Movie Equipment and Accessories • Geodetic Apparatus and Instruments • Photocameras, Binoculars, Magnifiers, Lenses, etc.


Detailed catalogues and pamphlets sent on request. All inquiries and correspondence to be forwarded to

V/O "STANKOIMPORT"

ul. Kuibysheva, 21, Moscow, USSR. For cables: Stankoimport Moscow.

DO NOT DETACH

## QUARTZ SPECTROGRAPH MODEL 1/CI 1-22



The UCII-22 Quartz Spectrograph has been designed to meet the need for an instrument of high optical quality to be used for both qualitative and quantitative WESTED AND THE emission spectrum analysis of ferrous and non-ferrous metals and alloys, ores, minerals and many other types of materials.

The instrument may also be used for absorption work.

The quality of the line imagery throughout the spectrum is exceptionally good, the lines being sharp and clean cut to the very ends of the plates.

The base of the spectrograph is constructed to take a bar, on which the electrode and condenser supports are mounted. The length of the bar is 1500 mm.

The slit is operated by a drum graduated to indicate slit widths in units of 0.01 mm.

The quartz prism is of the Cornu type, half of right, half of left-hand quartz, to neutralize the effects of double refraction.

A handwheel and screw mechanism serves to raise or lower the plate holder and permits the taking of as many spectra as desired on a single plate.

Approved For Release 2002/01/04: CIA-RDP83-00415R011900050001-3

## SPECIFICATIONS

Spectrum range			2000 A 6000 A
Spectrum length, mm			22.
Prisia .			
hoight, mm			36.
base, mm			4/
refracting angle			-6C
anaular dispersion			9/4C
Prism is set for minimum beam deviation on wave length			25/3Å
Camera objective		white or	gentz, ach omatic
Tocal length of objective (25/3A) in many control of the control o			831
Focal length of objective (5593Å), mer			921
Diameter of objective, mm			4.
Full aperture of collimator			4.3
tinear magnification of spectrograph (ratio of focal let a	ris of politicational The second	сатон	1.5%
Making deviation of tocal plane from plane plane """	· ·		\$2.44
electric sunply for spark generalise			in a 120 – 20 v. - A C mader
Dyerall dimensions of instrument weight x width x neigh-	mm .		1705 kv00×460
Herant of optical axis above table surface, mm			J.)
Height of optical axis above bar serface, it is a second			2_3
Height of instrument above table seriach, nin			360
Weight of instrument, complete, kg			[]
Weight of instrument in carrying race, sq			· J

## ACCESSORIES

Contented supplied alppar e octrode succ. It : pwer electrode success loack generator. Set all scarb **pirts** a miller**v** se to ds Carrying case

## VSESOJUZNOE EXPORTNO-IMPORTNOJE OBJEDINENIJE

## "STANKOIMPORT" EXPORTS AND IMPORTS

Machine Tools • Metal-Working Machinery • Wood-Working Machinery • Measuring Instruments and Apparatus • Metal and Wood Cutting Tools • Portable Electric and Pneumatic Tools • Carbide Tips and Special Carbide Products • Grinding Wheels • Ball and Roller Bearings • Meta-urgical, Biological and Medical Microscopes • Movie Equipment and Accessories • Geodetic Apparatus and Instruments • Photocameras, Binoculars, Magnifiers, Lenses, etc.

> Detailed catalogues and pamphlets sent or request. All inquiries and correspondence to be forwarded to

> > V/O "STANKOIMPORT

ul. Kuibysheva, 21, Moscow, USSR. For cables: Stankoimport Moscow.

DO NOT DETACH


## SPECTRUM PROJECTOR MODEL TC-18

The most convenient and least fatiguing method of observing spectrum negatives is to project their enlarged images upon a screen where they can be seen under normal conditions of vision.

The ITC-18 Spectrum Projector has been designed to make full use of the advantages of the projection method of examination.

The projection surface is horizontal and formed upon the base of the instrument, above which the projection system is supported on a rigid framework.

The negative which is to be projected is supported on a horizontal mechanical stage whose rack - and - pinion motions are controlled by extended shafts with handles conveniently placed for the observer. The stage will accomodate any size of plate up to 13×24 cm and has spring clips for holding the plate in position.



A magnification of 20 imes is obtained by means of a specially selected projection lens of great light gathering power and with sharp definition.

The projection unit is furnished with a well ventilated lamphouse with condensing lens system, and an 11 volt 100 watt lamp. The latter is run conveniently from a transformer connected with A. C. mains.

The instrument provided also for photographing the enlarged image of spectrograms.

The Spectrum Projector finds wide application in industrial and educational laboratories.

					ля. Б.: <b>13 -</b> 94
					Of: 2
rum line	distances, n			• •	. 0.01
					7 7 7 I
					1 0
					-97
					£4.5
					30
ngth « w	inth x height:	nna			-60/5 x 555 x 90%
	****				35
- in ee	riying case, ir				81
	rum lige	rum Fre distances, non-	rum Pre distances, need a second seco	rum Pre distances, mm	rum Free distances, non

## ACCESSORIES

Transformer 120-22011? Sim of loane parts and it invice tool Currying case.



VSESOJUZNOE EXPORTNO-IMPORTNOJE CAJEDINENIJE

## "STANKOIMPORT"

EXPORTS AND IMPORTS:

Machine Tools • Metal-Working Machinery • Wood-Working Machinery • Measuring Instruments and Apparatus • Metal and Wood-Cutting Tools • Portable Electric and Pneumatic Tools • Carbide Tips and Special Carbide Products • Grinding Wheels • Ball and Roller Bearings • Metallurgical, Biological and Medical Microscopes • Movie Equipment and Accessories • Geodetic Apparatus and Instruments • Photocameras, Binoculars, Magnifiers, Lenses, etc.

Detailed catalogues and pamphlets sent on request. All inquiries and correspondence to be forwarded to

V/O "STANKOIMPORT"

ul. Kuibysheva, 21, Moscow, USSR. For cables: Stankpimport Moscow.


Order No. 133

Mezhdunarodnaya Kniga

THIS IS AN ENCLOSURE TO DO NOT DETACH

25X1A

## STEELOSCOPE MODEL СЛ-З



The  $C\Lambda$ -3 Steeloscope is a specialised spectroscope for the rapid estimation of metallic elements in steels.

The instrument enables the presence of the metals Chromium, Nickel, Tungsten, Vanadium, Cobalt, Molybdenum and Manganese to be detected at once in steel bars, steel scrap or steel work-pieces even by an unskilled observer. A few days' experience with bars of known chemical content will enable the operator also to state the approximate percentage present.

Specimens of the alloy under examination are used as one pole of an electric arc, the other pole being a rod of iron. The light from the arc is spread out by the steeloscope into a series of lines whose positions are distinctive of the metals present in the specimens.

The apparatus consists of two tubes-collimator and telescope-joined by a metal body. The body contains the prisms which produce the spectrum.

The collimator has a narrow slit through which the light from the specimen passes into the steeloscope. The telescope has an eyepiece which can be moved to definite positions indicated by engraved chemical symbols. At each position can be seen the most distinctive spectrum lines of the metal whose symbol is there inscribed.

The Steeloscope is used in stores, scrap yards, workshops and laboratories.

## SPECIFICATIONS

Working spectrum range		3890 Å— 6700 Å
Interchangeable telescope eyepieces		12.5 x and 20 x
Magnification of telescope:		
with eyepiece 12.5 x		19 x
with eyepiece 20 x		30.4×
lelescope objective		two-lens, adiromatic, focal length 380 mm
Columatar:		
width of slit, mm		
objective		two-lens, advromatic, focal length 190 mm
Dispersing system:		
number of prisms	The second secon	.3
prisms made of		flint glass with refractive index L54/5
refracting angle	the second secon	5() <sup>9</sup>
angular dispersion (4341 A - 5x93 A)		60 ()91
Current required		- 1 - 2 KW. D C持 - お
Time required for the analysis of a specimen, min		2-3
ACCESSORIES		
con bar supplier		
Condenser		1
Rheostat		er S
Lwo iron bar		
Carrying cos		
~ -1. X 11.34 12.13		

## VSESOJUZNOE EXPORTNO-IMPORTNOJE CBJEDINENIJE

## "STANKOIMPORT" EXPORTS AND IMPORTS:

Machine Tools • Metal-Working Machinery • Wood-Working Machinery • Measuring Instruments and Apparatus • Metal and Wood-Cutting Tools • Portable Electric and Pneumatic Tools • Carbide Tips and Special Carbide Products • Grinding Wheels • Ball and Roller Bearings • Metallurgical, Biological and Medical Microscopes • Movie Equipment and Accessories • Geodetic Apparatus and Instruments • Photocameras, Binoculars, Magnifiers, Lenses, etc.

Detailed catalogues and pamphlets sent on request. All inquiries and correspondence to be forwarded to

V/O "STANKOIMPORT"

ul. Kuibysheva, 21, Moscow, USSR. For cables: Stankoimport Moscow.


THIS IS AN ENCLOSURE TO DO NOT DETACH

## SLIT LAMP MÖDEL LITT

25X1A

The Model LLA Slit Lamp is a medical instrument that permits the ophthalmologist to make a differential diagnosis in many cases of eye pathology. Cellular and allied pathological changes within the media of the eye may be diagnosed long before the appearance of clinical symptoms. The instrument is almost indispensable to the ophthalmologist for routine procedure as well as scientific investigations.

The binocular microscope supplied with the instrument has two focusing adjustments in the vertical and horizontal directions. The microscope may be also rotated around a vertical axis. The revolving nosepiece fitted with paired objectives of 2x and 4x, permits quick changes of magnification. Three paired eyepieces of 4x, 10x and 15x are supplied, giving a range of total magnification from 8x to 60x. The illumination system applied is the most flexible and efficient for examination of the human eye. The



intensely illuminated slit of light may be varied in length and width. The condensing lens system, with the objective lens enables the operator to focus a slit of light to a narrow, sharply defined beam.

The chin-rest post has a manual forward and backward movement on a horizontal sleeve. Fine movement is obtained through the use of a micrometer screw. The chin-rest post has also a rotation around a vertical axis, thus providing changes of its position to the microscope and lamp.

### **SPECIFICATIONS**

Range of total magnification	8x to 60x
Paired objectives	2x and 4x
Paired eyepieces	4x, 10x and 15x
Source of illumination	bulb, 25 w, 12 v.
Transformer for reducing A. C. mains (120—220 v.) down to	12 v.

#### **ACCESSORIES**

Two paired objectives
Three paired eyepieces
Change chin-rest post

Five spare bulk : Carrying case



# THE ALL-UNION CORPORATION ,,STANKOIMPORT" EXPORTS AND IMPORTS:

Machine Tools • Metal-Working Machinery • Wood-Working Machinery • Measuring Instruments and Apparatus • Metal and Wood-Cutting Tools • Portable Electric and Pneumatic Tools • Carbide Tips and Special Carbide Products • Grinding Wheels • Ball and Roller Bearings • Metallurgical, Biological and Medical Microscopes • Movie Equipment and Accessories • Geodetic Apparatus and Instruments • Photocameras, Binoculars, Magnifiers, Lenses etc.


Detailed catalogues and pamphlets sent on request.

All inquiries and correspondence to be forwarded to

V/O "STANKOIMPORT"

ul. Kuibysheva, 21, Moscow, USSR. For cables: Stankoimport, Moscow.

# OPTICAL DIVIDING HEAD MODEL **ОДГ**



The OPTICAL DIVIDING HEAD **OAT** is a high precision instrument designed for laying out and checking angular spacing and angular locations of gear teeth, splines, cams and other different work pieces.

The graduated circle of the instrument is mounted co-axially with the main spindle and its movement is observed with a microscope, having a scale fixed at the focal plane of the eyepiece.

The dividing head is mounted in a cradle in order that the measuring spindle may be capable of adjustment through 90° in the vertical plane. An exterior scale and vernier are provided to facilitate this.

The instrument has been built to provide a standard of angular measurement to satisfy the most exacting requirements in engineering production.

Magnification of microscope		60 x
Scale of circle graduated to	,	Lo
Eyepiece scale graduated to		1,
Guaranteed accuracy of instrumen:		
when used for measuring		20"
when used for machining purposes (drillion, milling)		
Adjustment of measuring spindle in vertical plane		90°
Vernier reading of exterior scale	 	6'
Height of center above base, mm		130
Taper hole in spindle		Morse No. 4
Overall size of dividing head, mm.		
Overall size of tailstock, mm		
Weight of dividing head and tailstock, kg.		

### **ACCESSORIES**

Tailstock
Work driver
Headstock center
Set of wrencties
Spare lamps



## THE ALL-UNION CORPORATION

## "STANKOIMPORT"

**EXPORTS AND IMPORTS:** 

Machine Tools • Metal-Working Machinery • Wood-Working Machinery • Measuring Instruments and Apparatus • Metal and Wood-Cutting Tools • Portable Electric and Pneumatic Tools • Carbide Tips and Special Carbide Products • Grinding Wheels • Ball and Roller Bearings • Metallurgical, Biological and Medical Microscopes • Movie Equipment and Accessories • Geodetic Apparatus and Instruments • Photocameras, Binoculars, Magnifiers, Lenses etc.

Detailed catalogues and pamphlets sent on request.

All inquiries and correspondence to be forwarded to


VIO "STANKOIMPORT"

ul. Kuibysheva, 21, Moscow, USSR. For cables: Stankoimport, Moscow.

THIS IS AN ENCLOSURE TO DO NOT DETACH

25X1A

# VERTICAL OPTICAL COMPARATOR MODEL **HKB**



AESTAICTED

The Model **UHB** Vertical Comparator is a precision measuring instrument designed for making external measurements on various types of objects in the toolroom, inspection room and laboratory.

The instrument acts as a comparator between the gauge block and the object being measured.

An attachment for the projection of the comparator scale on a special screen, and a fixture for measuring wire diameter, can be supplied at extra cost.



#### SPECIFICATIONS

Graduation of scale, mm	0.001
Range of scale, mm	± 0.1
Accuracy of measurement, mm	$\pm$ 0.0003
Maximum height of work checked, mm	180
Maximum external diameter checked, mm	150
Measuring pressure, g	$200\pm20$
Overall dimensions, mm	(240 x 560
Net weight, kg	40

### STANDARD EQUIPMENT

Fixture for measuring block gauges
Spherical contact tip
Flat contact tip
Three back stops
Adjustable mirror for scale illumination
Frigger release

## ",STANKOIMPORT" EXPORTS AND IMPORTS:

Machine Tools • Metal-Working Machinery • Wood-Working Machinery • Measuring Instruments and Apparatus • Metal and Wood-Cutting Tools • Portable Electric and Pneumatic Tools • Carbide Tips and Special Carbide Products • Grinding Wheels • Ball and Roller Bearings • Metallurgical, Biological and Medical Microscopes • Movie Equipment and Accessories • Geodetic Apparatus and Instruments • Photocameras, Binoculars, Magnifiers, Lenses etc.

Detailed catalogues and pamphlets sent on request. All inquiries and correspondence to be forwarded to

VIO "STANKOIMPORT"

ul. Kuibysheva, 21, Moscow, USSR. For cables: Stankoimport, Moscow.

THIS IS AN ENCLOSURE TO DO NOT DETACH

25X1A

## VERTICAL COMPARATOR MODEL **H3B-1**

The M3B-1 Vertical Comparator is designed for absolute measurements of length of any objects within its range.

The instrument consists essentially of a massive stand carrying a worktable, measuring head and a microscope.

The measuring head plunger, which contacts with the work, controls the movement of the glass scale having 100 divisions, each division being equal to 1 mm.

Objects from 100 mm up to 250 mm are measured by resetting the measuring head using gage blocks.

MESTRICIED

The glass scale is viewed through the micrometer eyepiece of the microscope reading to 0.001 mm. Estimations can easily be made to tenths of a micron.

The glass scale is illuminated by light from an electric lamp passed through a green filter.

The instrument is provided with three forms of tips. The tips are easily interchanged by releasing the small clamp screw.

Maximum measuring range:							
without gage blocks in	m.					(	
using gage blocks, mm						e. L :	
Class scale reading, mm							
M.crometer eyepiece reading, m	m						
Alcuracy of measurement, mm						1.001	
			;	ogtiration i	ord at word	200	00C
Microscope magnification						7 C 7	
Measuring pressure, g						151 250	
Surface of work table, mm						95 ₹140	
Distance, Center of measuring pl.	inger to	oumn, m	m			11.	
Source of Mumination						Fu 5-3.5 . ; 125 ann	
Correst supply						11 220 . 4 (	
ine get of instrument, mm						72."	
Width of instrument, mm						24C	
Weight of instrument, kg	•			• • • • •		tanrox. £1	

VSESOJUZNOE EXPORTNO-IMPORTNOJE DBIEDINENIJE

## "STANKOIMPORT'

**EXPORTS AND IMPORTS** 

Machine Tools • Metal-Working Machinery • Wood-Working Machinery • Measuring Instruments and Apparatus • Metal and Wood-Cutting Tools • Portable Electric and Pneumatic Tools • Carbide Tips and Special Carbide Products • Grinding Wheels • Ball and Roller Bearings • Metal orgical, Biological and Medical Microscopes • Movie Equipment and Accessories • Geodetic Apparatus and Instruments • Photocameras, Binoculars, Magnifiers, Lenses, etc.

Detailed catalogues and pamphlets sent or request. All inquiries and correspondence to be forwarded to

V/O "STANKOIMPORT"

ul. Kuibysheva, 21, Moscow, USSR. For cables: Stankoimport Moscow.

Prefer No. 135

Mezhdunarodnaya Kniga


proved For Release 2002/01/04 : CIA-RDP83-00415R011900

THIS IS AN ENCLOSURE TO

# HORIZÖNTAL OPTICAL COMPARATOR

25X1A

MODEL HKT



The Model **UHF** Horizontal Comparator is a precision instrument, which is very convenient in making external and internal measurements on plain and thread gauges and on various types of objects in the toolroom, inspection room and laboratory.

The instrument acts as a comparator between the gauge block and the object being measured.

An attachment for the projection of the comparator scale on a special screen, and one pair of hanger arms for internal measuring up to 5 mm. diameter, can be supplied at extra cost.



Graduation of scale, mm	0.001
Range of scale, mm	- 0.1
Accuracy of measurement, mm	£ 0.0003
Maximum external diameter checked, mm	350
Maximum internal diameter checked, mm	150
Minimum internal diameter checked, mm	13.5
Minimum internal diameter checked with special hanger arms, mm	5
Maximum height of ring gauge checked, mm	56
Vertical table movement, mm	86
Measuring pressure, g	200 走 20
Overall dimensions, mm	875 x 300 x 340
Net weight, kg	48

#### STANDARD EQUIPMENT

One pair of hanger arms for internal measuring up to 13 5 mm diameter. Two spherical contact tips

Two flat contact tips

Vee blocks and clamps

Adjustable mirror for scale illumination

Trigger release

II to the trade of the street of the street

#### THE ALL-UNION CORPORATION

## "STANKOIMPORT"

EXPORTS AND IMPORTS:

Machine Tools • Metal-Working Machinery • Wood-Working Machinery • Measuring Instruments and Apparatus • Metal and Wood-Cutting Tools • Portable Electric and Pneumatic Tools • Carbide Tips and Special Carbide Products • Grinding Wheels • Ball and Roller Bearings • Metallurgical, Biological and Medical Microscopes • Movie Equipment and Accessories • Geodetic Apparatus and Instruments • Photocameras, Binoculars, Magnifiers, Lenses etc.


Detailed catalogues and pamphlets sent on request.

All inquiries and correspondence to be forwarded to

VIO "STANKOIMPORT"

ul. Kuibysheva, 21, Moscow, USSR. For cables: Stankoimport, Moscow.

# HORIZONTAL COMPARATOR MODEL **H3A-2**



The U3A-2 Horizontal Comparator is designed for the measurement of spectrograms, linear scales and any length within the range of the instrument master scale.

The instrument consists essentially of two fixed microscopes and one moving stage on which the master glass scale and the specimen being measured are mounted.

The arc-type support on which the microscopes and stage are mounted permits the instrument to be operated either vertically (the object horizontal) or inclined at  $45^{\circ}$  for greater convenience.

Both rough and fine adjustments of the longitudinal movement of the stage are provided.

The microscope set over the specimen being measured has two interchangeable reticles while the measuring microscope set over the master scale is supplied with a micrometer eyepiece which reads direct to 0.001 mm. Estimations can easily be made to tenths of a micron.

The comparator is used in measuring laboratories of metal working industries and scientific research institutes.

Magnification of object microscope	 from $7x$ to $10.5$
Magnification of measuring microscope	 61.5 x
Range of measurement, mm	 0 -200
Accuracy of measurement, mm	 0.001
Lemperature rate when measuring	 2∪ ± 0.2° C
Overall dimensions of instrument rength x width X height , mm	 6iJ×300×390

### VSESOJUZNOE EXPORTNO-IMPORTNOJE OBJEDINENIJE

## "STANKOIMPORT"

EXPORTS AND IMPORTS

Machine Tools • Metal-Working Machinery • Wood-Working Machinery • Measuring Instruments and Apparatus • Metal and Wood-Cutting Tools • Portable Electric and Pneumatic Tools • Carbide Tips and Special Carbide Products • Grinding Wheels • Ball and Roller Bearings • Metallurgical, Biological and Medical Microscopes • Movie Equipment and Accessories • Geodetic Apparatus and Instruments • Photocameras, Binoculars, Magnifiers, Lenses, etc.

> Detailed catalogues and pamphlets sent on request. All inquiries and correspondence to be forwarded to

> > V/O "STANKOIMPORT"

ul. Kuibysheva, 21, Moscow, USSR. For cables: Stankoimport Moscow.


DHR Arphored to release 2002/01/04-3CIA-RDP

# HARDNESS TESTING MACHINE

(ROCKWELL PRINCIPLE)

THIS IS AN ENCLOSURE TO

25X1



V/O Stankonny Moscow - Ussr

The PB Direct-reading Hardness Testing Machine is designed to perform the Rockwell tests in laboratories and works, using a hardened steel ball or a diamond cone penetrator.

The test is standardized and is performed in the following stages:

A minor load is applied to the penetrator to eliminate effects on the final reading due to surface imperfactions in the objects under examination and provide a datum for hardness measurement. A major load is then added and the depth of penetration produced by increment of load is taken as the measure of hardness. A reading is made directly on a scale, which is arranged so that the deeper the penetration the lower the reading. The number is therefore a direct measure of the hardness.

The load is applied by standardized dead weights and lever.

The load is held for the standard test period of 5-6 sec.

The specimen to be tested is carried on the table of the machine and is brought into contact with the ball or diamond cone penetrator by turning the handle on the table elevating screw.

## SPECIFIC'ATIONS


PB

Annual Company of Company
distant

THIS IS AN ENCLOSURE TO

## 25X1A

## DOUBLE SPECTRUM PROJECTOR, MODEL ДСП-1



The most convenient and least fatiguing method of observing spectrum negatives is to project their enlarged images upon a screen where they can be seen under normal conditions of vision.

The  $AC\Pi$ -1 Double Spectrum Projector has been designed to make full use of the advantages of the projection method of examination.

The projection surface is horizontal and formed upon the base of the instrument, above which the projection system is supported on a rigid framework.

The instrument enables simultaneous projection of two spectrograms so that they can be viewed in direct comparison with known or standard spectrograms.

The Double Spectrum Projector is used in scientific research institutes and industrial laboratories.

Magnification	 25 €
Length type projection lens:	
focal lengh!, mm	327
full aperture	 F 3.5
the arcord aight	 12x, 19 w. lem:
These values for reducing A.C. mains (120 - 22) vito	 12 v
¿)verall and instans of instrument, mm	5/0 x c00 x 9ep
Weight of instrument, kg	 40.0
Weight of instrument with case, kg	164.



### VSESOJUZNOE EXPORTNO-IMPORTNOJE OBJEDINENIJE

## "STANKOIMPORT" EXPORTS AND IMPORTS:

Machine Tools • Metal-Working Machinery • Wood-Working Machinery • Measuring Instruments and Apparatus • Metal and Wood-Cutting Tools • Portable Electric and Pneumatic Tools • Carbide Tips and Special Carbide Products • Grinding Wheels • Ball and Roller Bearings • Metallurgical, Biological and Medical Microscopes • Movie Equipment and Accessories • Geodetic Apparatus and Instruments • Photocameras, Binoculars, Magnifiers, Lenses, etc.

Detailed catalogues and pamphlets sent on request. All inquiries and correspondence to be forwarded to


V/O "STANKOIMPORT"

บไ. Kuibysheva, 21, Moscow, USSR. For cables: Stankoimport Moscow.

Order No. 132

Mezhautarodnava Kriat

THIS IS AN ENCLOSURE TO DO NOT ESTACH



25X1A

## CONTOUR MEASURING PROJECTOR, MODEL **5**1


The BII Contour Measuring Projector is an optical projection machine for measuring or comparing objects by means of a magnified shadow. This instrument has many applications in the rapid inspection and measurement of: contour of forming tools, form of cams, screw threads, thread gauges, hobs, form of gear teeth, form and dimensions of punches and dies, irregularly shaped production parts, etc. It permits also drawing with high precision the contour of an object under investigation.

The stage and horizontal screen are so positioned that the operator's vision takes in both the object to be measured and the enlarged shadow reflected on the screen.

Without experience or special training, any shopman can operate the machine with speed and precision. Its scope of usefulness embraces a large variety of work in production, toolroom, inspection, or laboratory.

Essentially, the Projector consists of a suitable light source, whose beams are directed through a set of condensing lenses, projection lens, which function as a magnifying agent. The magnified image is projected on a properly situated mirror, which directs it onto a conveniently positioned viewing screen.

The stage upon which the specimen is placed is provided with a circular movement with graduated scale and vernier reading to 3'.



The linear movements of the stage slides are controlled by two micrometer screws and have a range of 25 mm in either direction in the horizontal plane. The insertion of gauge blocks increases the longitudinal range to 150 mm and the transverse range to 50 mm.

The instrument may be used for both transmitted and reflected light work.

## **SPECIFICATIONS**

Magnifications of Projector	10x, $20x$ and $50x$
Fields of view (object diameter completely imaged on the screen) mm	60, 30 and 12
Maximum stage travel, mm:	
longitudinal	150
transverse	50
vertical	100
Reading of stage micrometer screws, mm	0.005
Circular stage graduated to 1°, reading to, minutes	3
Stage slides swivel	
Maximum size of work under investigation, mm:	
length	330
diameter	150
Source of illumination	bulb, 100 w. 12 v.
Transformer for reducing A. C. mains (120—220 v.) down to 12 v.	
Overall dimensions, mm	2100x1200x900
Overall dimensions, mm	350
Weight of instrument, kg	J00

## ACCESSORIES

V-blocks Centers and centers' support object clamp objective 2x objective 50x Illumination centering attachment Mirror protector Gauge block fixing—lide Set of gauge blocks



# "STANKOIMPORT" EXPORTS AND IMPORTS:

Machine Tools • Metal-Working Machinery • Wood-Working Machinery • Measuring Instruments and Apparatus • Metal and Wood-Cutting Tools • Portable Electric and Pneumatic Tools • Carbide Tips and Special Carbide Products • Grinding Wheels • Ball and Roller Bearings • Metallurgical, Biological and Medical Microscopes • Movie Equipment and Accessories • Geodetic Apparatus and Instruments • Photocameras, Binoculars, Magnifiers, Lenses etc.

Detailed catalogues and pamphlets sent on request.

All inquiries and correspondence to be forwarded to

VIO "STANKOIMPORT"

ul. Kuibysheva, 21, Moscow, USSR. For cables: Stankoimport, Moscow.